GIOVENZANA INTERNATIONAL B.V. Strawinskylaan, 1105 1077 XX Amsterdam, THE NETHERLANDS Ph: +31 (0) 20.4413576 E-mail: giovenzana@giovenzana.com

G.T.R. LLC

Likhov lane, h.3, b.2, office 2-9 127051, Moscow, RUSSIAN FEDERATION Ph: +7.499.9228548 E-mail: gtr@giovenzana.com

GIOVENZANA CONTROLS INDIA Pvt. Ltd.

A-102, Knox Plaza, Chincholi, Off Link Road Near Mindspace, Malad West 400064 Mumbai, INDIA Phone: +91.22.42640071 E-mail: ggindia@giovenzana.com

GIOVENZANA CONNECTING BRASIL LTDA

Rua Dante Razeira, 102 Cep. 92700-090 Guaĺba, Rio Grande do Sul, BRASIL Ph: (+55) 51 3055 1033 E-mail: gcb@giovenzana.com

GIOVENZANA INTERNATIONAL B.V. - Dubai Branch

Jafza 15, Jebel Ali Free Zone P.O. Box 262146 Dubai, U.A.E. Ph: +971.4.8870788 E-mail: uae@giovenzana.com



www.giovenzana.com



GIOVENZANA INTERNATIONAL B.V.



ENERGY TRANSMISSION SYSTEM BUSBAR - MULTIPOLE - FESTOON





PRODUCTS INDEX

Line construction																	LIN	E TYP	E/AN	1PERA	GE CO	VERAGE
8 Technical Data - Busbar and M	ultipole System										MP	04P				40A	50A	60A	70A	100A	140A	160A 200A 32
			LIN	E TYP	E / AM	MPERAGI	E CO\	VERAG	GE		28/2	29 F	Pre-Mounted Conductors		Mind			60A		100A	140A	
R60		40A	50A	60A	70A	100A 14	10A 1	160A 2	200A 32	20A		4	l Poles		4 Poles							
Continuous conductors Max 5 Poles		40A		60A							30/4	1	FESTOON SYSTEM									
	Max 5 conductors slot										32	L	Line construction									
Pre-mounted conductors Max 5 Poles		40A		60A							LIN	IE 3	0									
Max 5 Foles	4 poles 5 poles										34/3	35	Standard									
R85H5P		40A	50A	60A	70A	100A 14	10A 1	160A 2	200A 32	20A	0-1/0		(also available for HAZARDOUS LOCATIO)NS)**								
	7 T										LIN	IE 4	1									
Continuous conductors Max 5 Poles	Max 5 conductors slot	40A			70A	100A 14	AOI				36/3		Standard (also available for HAZARDOUS LOCATIO	NS)**								
Dre mounted conductors													and available for the America	,,,,,								
Pre-mounted conductors Max 5 Poles		40A			70A	100A 14	AO4				36/3	37	Stainless Steel									
R85H7P	4 poies 3 poies	40A	50A	60A	70A	100A 14	10A 1	160A 2	200A 3	 20A			UDE DOD							• • • • • • • •		
	Record .	1011	0021								LIN	IE W	/IRE-ROP									
Continuous conductors Max 7 Poles			50A			100A	1	160A 2	200A 32	20A *	38		Standard		0							
	Max 7 conductors slot												·BEAM									
/21 Pre-mounted conductors Max 7 Poles			50A			100A	1	160A 2	200A 32	20A *	211		DEAM									
	7 poles				* (Only 4 pole	es with	h paralle	el connect	ions	38		Light Series									
/23 Accessories						, .		•					AND ROUND CABLES							• • • • • • • •		
/25 Survey											40		Flat cables and round cables wit	h dual st	rain relief cords							

Energy Transmission Systems - Rev. 02/2023

GIOVENZANA INTERNATIONAL B.V. reserves the right to modify, all technical and functional characteristics of the products shown in this flyer without prior notice as this information is intended for general knowledge and is not legally binding. Images are intended for illustrative use only.

BUSBAR




BUSBAR SYSTEM

The **Conductor Busbar System** is a modern and safe power transmission system for various types of equipment, such as cranes, overhead cranes, conveyor belts, chain conveyors, etc...

The busbar system complies with relevant international standards, ensuring operator safety, ease of installation and reliability. The "H" honeycomb profile of the TR85H line ensures greater strength and light weight.

TYPICAL LAYOUT



1	BUSBAR	PVC Housing
2	TROLLEY CURRENT COLLECTOR	Transmits the energy from the conductor to the machine
3	HEAD FEED BOX	Connects power supply to the conductor
4	JOINT BOX	Links two busbars
5	END CAP	Closes and protects the busbar end
6	IN-LINE FEED BOX	Connects power supply from centre to avoid the voltage drop
7	HANGER CLAMP	Connects the busbar to the brackets
8	COPPER STRIP	Transmits the energy from the power supply to the current collector
		Concotor
9	FIXED POINT	Creates a fixed point

TYPICAL APPLICATIONS



CRANE TECHNOLOGY

Cranes and Hoists Recycling plans Galvanized plants



PRODUCTION AUTOMATION

Electric systems Automated conveyors



BMU


Cleanroom technology

Building Maintenance Units Airport and terminal stations Skyscrapers




PEOPLE MOVER SYSTEM

People movers Vertical elevators Inclined elevators



STORAGE





AGRICULTURE


AIRCRAFT HANGAR DOORS

AVAILABLE VERSIONS

RSIONS


A. CONTINUOUS CONDUCTORS

The conductors are pulled from a coil without joints into the already installed casing.



B. PRE-MOUNTED CONDUCTORS

The conductors are already inserted in the plastic casing.



BUSBAR SYSTEM

LINE CONSTRUCTION

When deciding on the size of the trolleys, it is necessary to consider:

- Maximum current in service;
- Devices (cage motors, slip-rings motors, resistors, electronic starters);
- · Starting current of the devices;
- · Maximum ambient temperature;
- · The distance between device to the nearest power supply;
- · Allowable voltage and voltage drop in continuous duty and starting;
- Type of current;
- Duty cycle of the devices (load factor).

CALCULATION OF THE VOLTAGE DROP

• The voltage drop must not exceed 5% of the rated voltage under normal operating conditions.

Three-phase alternating current:

 $\Delta u = \sqrt{3} \times I \times Lt \times Z$ $\Delta u\% = \frac{\Delta u \times 100}{U}$

 Δu = Voltage drop [V] $\Delta u\%$ = Voltage drop [%] I = Current intensity [A] Lt = Length of section [m] Z = Impendence [Ω/m] U = Voltage [V]


Keys:

POWER FEED: BUSBAR TRACK LENGHT

• Proper arrangement of power points minimizes voltage reduction.

If "L" is the line length, "Lt" is the maximum track length to consider voltage reduction.

- A Lt = L with ending/starting power feed
- B Lt = L/2 with in-line power feed
- Lt = L/6 with power feed at 1/6 from each end
- Lt = L/10 with three power feed at L/2 and L/10 from each end



CURRENT IN CONTINUOUS SERVICE

TECHNICAL DATA

· Specify the number of devices working simultaneously to calculate the corresponding current:

$$ln = l_1 + l_2 + l_3 + ...$$

• The current can be determined by the power of the devices [W], which, for a three-phase system, is equal to:

In =
$$\frac{Pu}{\sqrt{3} \times U \times \cos \varphi \times \eta}$$

Keys:

In = Current consumption [A]
Pu = Power devices [W]
η = Devices performance
U = Operating Voltage [V]
cosφ = Power factor

• In the absence of information on the operation of simultaneous devices, consider the following table:

	LIFTING EQUIPMENT IN USE									
N° OF IN-LINE LIFTING DEVICE	1 ST ENGINE	2 ND ENGINE	3 TH ENGINE	4 TH ENGINE						
	max power engine*		decreasing power engine*							
1	х	х								
2	Х	х	X							
3	Х	Х	Х							
4	Х	Х	Х	х						
5	х	Х	X	х						
N° 2 lifting equipment operating simultaneously	х	х	X	Х						

^{*} About η motors connected in parallel with rated current In', consider In = $\eta \times In'$.

STARTING CURRENT

• Calculate the numbers of simultaneously started devices and the device already in service, then calculate the corresponding current. If the startup current is not known, proceed with the following approximation:

For a single user $Ia = K \times In \qquad K = \underbrace{Starting\ current\ (Ia)}_{Nominal\ current\ (In)}$

As a general rule, consider: K = 5 to 6 for cage motors K = 2 for winding motors K = 2 for inverters (frequency converters)

7

• In the absence of information on the operation of simultaneous devices, consider the following table:

	LIFTING EQUIPMENT IN USE											
N° OF IN-LINE LIFTING DEVICE	1 ST ENGINE		2 ND EN	GINE	3 TH EN	GINE	4 [™] ENGINE					
	la	In	la	In	la	In	la	ln				
1	х			х		•						
2	х			х		х						
3	Х		х									
4	Х		Х			х						
5	х		x			Х		Х				
N° 2 lifting equipment operating simultaneously	х		x			х		х				



TECHNICAL DATA

GENERAL CHARACTERISTICS

	TR	160		TR8	5H5P		1	R85H7	Ρ	MP04P		
	40	60	40	70	100	140	50	100-200*	160-320*	60	100	140
Operating current 23°C	40A	60A	40A	70A	100A	140A	50A	100A	160A	60A	100A	140A
Comply with standards			CE	I EN 6043	39-1, CEI EI	N 60439-2	, CEI EN 6	0695-2-1,	CEI EN 605	570		
Markings						(€	ERC					
Rated operating voltage [Ue]						600	0Vac					
Frequency						50	OHz					
Conditional short circuit withstand current						10) ka					
Fuse rating gG	40A	60A	40A	70A	100A	140A	50A	100A	160A	60A	100A	140A
Protection class CEI EN 60529		IP13 (IP44 with gasket accessories) IP20										
Flammability resistance of the busbar:												
UL94		V0										
Cei EN 60695-2-1						96	0°C					
Ambient Temperature												
operating						-30°C	+55°C					
storage						-30°C	+70°C					
Max admissible trolley speed				20	00 m/min ⁻¹					4	400 m/min	1 ⁻¹
ETP Copper strip section [mm²]	10 10×1	15 10×1,5	9,3 15,5×0,6	15,5 15,5×1	23,25 15,5×1,5	31 15,5×2	10 12,5×0,8	22,5 12,5×1,8	31,25 12,5×2,5	15	24	32
Resistance [Ω/m 10 ⁻⁴]	17	11,33	18,27	10,96	7,83	5,48	17	8,38	5,29	11,33	7,83	5,48
Impendence [Ω/m 10 ⁻⁴]	17,09	11,38	18,36	11,01	7,87	5,55	17,09	8,42	5,36	11,38	7,87	5,55

^{* 200}A and 320A models are obtained in parallel configuration, thus for 4 poles only. Values given are for the single conductor.

CONDUCTORS BARS WEIGHT TABLE (complete of conductors)

		TR	60		TR85H5P			T	R85H7	P	MP04P		
		40	60	40	70	100	140	50	100	160	60	100	140
Weight [l	(g/m] +/- 50g	•											
•	4 poles	1,05	1,25	1,40	1,65	1,95	2,25	-	-	-	1,25	1,54	1,83
•	5 poles	1,15	1,35	1,50	1,80	2,15	2,55	-	-	-	-	-	-
	7 poles	-	-	-	-	-	-	1,70	2,30	3,05	-	-	-

PVC BUSBAR CHARACTERISTICS

MATERIAL	CERTIFICATIONS	RIGID PVC
	UL94	V0
Self-extinguish	DIN 4102	B2
	D.M. 6/7/83	CI
Ultimate tensile strenght	ISO R527 23°C	430 kg/cm³
Yield point	ISO R527 23°C	460 kg/cm³
Modulus of elasticity	ISO R178 23°C	30.000 kg/cm³
Impact resistance	DIN 53453	Unbroken
Dielectric strenght	ASTM 149	25 kv/mm
Softening temperature - Vicat	ISO R306 49N	82°C



TR60 continuous conductors

ITEM	PRODUCT	SPECIFICATION	40A	60A
BUSBAR	GIOUENZANF	Standard lenght: 4 meters *. Material: PVC.	TR6	000W
CONDUCTOR SIZE		ETP copper.	CS40 10×1 - 10mm²	CS60 10×1,5 - 15mm²
JOINT BOX		Material: plastic. To connect two busbars.	TR6	001W
HANGER		Material: plastic. Max support spacing: 1,33 m.	TR6	002W
CLAMP		Material: steel. Max support spacing: 1,33 m.	TR	6020
END CAP	6	Material: plastic. Closes and protects the busbar end.	TR6	006W
FEED BOX		Material: plastic. To use to feed the line (at the head of the line).	TR6	003W
IN-LINE FEED		To use along the line in order to prevent voltage drop. Clamps or screws + nuts not included.	Recommended	008W use of dedicated s to page 23.
TROLLEY CURRENT COLLECTOR		25A - 4 conductors.	TR	6004
(for straight and curved lines)	Y	25A - 5 conductors.	TR	6005

ITEM	PRODUCT	SPECIFICATION	40A 60A
TOWING ARM		To use to move the trolley current collector.	TR8557
TOWING ARM BRACKET		Alternative product of TR8557 (with TR8510).	TR6007
TOWING ARM		To use with TR6007 or TR6013.	TR8510
DOUBLE TROLLEY SUPPORT		For utilization with two trolleys in order to have ampacity of 50A.	TR6013
FIXED POINT		Fix the line to control thermal expansion. One for each line.	TR6014W
TRANSFER GUIDE			TR6034
SPRING LOADED TOWING ARM		For transfer guide.	TR8538
GASKET IP44			TR6012
CONDUCTOR INSERTION TROLLEY		For insertion of copper conductor in the line.	TR6011
DE-COIL UNIT			TR8513



TR60 PRE-MOUNTED CONDUCTORS

ITEM	PRODUCT	SPECIFICATION	40A	60A		
	da	Standard lenght: 4 meters *. 4 conductors.	TR60404CW	TR60604CW		
BUSBAR		Standard lenght: 4 meters *. 5 conductors.	TR60405CW	TR60605CW		
		Conductor type.	Included in busbar code 10×1 - 10mm²	Included in busbar code 10×1,5 - 15mm²		
JOINT BOX		TR6001W				
HANGER		Material: plastic. Max support spacing: 1,33 m.	16002W			
CLAMP		Material: steel. Max support spacing: 1,33 m.	TR	5020		
END CAP		Material: plastic. Closes and protects the busbar end.	TR6	006W		
FEED BOX		4 conductors.	TR60	03A4W		
		5 conductors.	TR60	03A5W		
IN-LINE FEED		4 conductors.	TR60	08A4W		
IIV-LINE I LLD		5 conductors.	TR60	08A5W		
TROLLEY		25A - 4 conductors.	TR	5004		
CURRENT COLLECTOR		25A - 5 conductors.	TR6005			

ITEM	PRODUCT	SPECIFICATION	40A 60A
TOWING ARM		To use to move the trolley current collector.	TR8557
TOWING ARM BRACKET		Alternative product of TR8557 (with TR8510).	TR6007
TOWING ARM		To use with TR6007 or TR6013.	TR8510
DOUBLE TROLLEY SUPPORT		For utilization with two trolleys in order to have ampacity of 50A.	TR6013
FIXED POINT		To fix the line to control thermal expansion. 1 for each line.	TR6014W
		LEFT 4 conductors.	TR6034A4W
TRANSFER		LEFT 5 conductors.	TR6034A5W
GUIDE		RIGHT 4 conductors.	TR6035A4W
		RIGHT 5 conductors.	TR6035A5W
SPRING LOADED TOWING ARM		For transfer guide.	TR8538
GASKET IP44			TR6012



BUSBAR SYSTEM

TR85H5P CONTINUOUS CONDUCTORS

ITEM	PRODUCT	SPECIFICATION	40A	70A	100A	140A	
BUSBAR	GIOUENZI	Standard lenght: 4 meters *. Material: PVC.		TR85	H5PW		
CONDUCTOR SIZE		ETP copper.	RM40 15,5×0,6 9,3mm ²	RM70 15,5×1 15,5mm²	RM100 15,5×1,5 23,25mm ²	RM140 15,5x2 31mm ²	
		Material: plastic. To connect two busbars.	TR8501W				
JOINT BOX		Material: steel. To connect two busbars.	TR8524				
HANGER		Material: plastic. Max support spacing: 1,33 m.	TR8502W				
CLAMP	t l	Material: steel. Max support spacing: 1,33 m.	TR8525				
END CAP		Material: plastic. Closes and protects the busbar end.	TR8506W				
FEED BOX		Material: plastic. To use to feed the line (at the head of the line).	TR8503W				
IN-LINE FEED		To use along the line to prevent voltage drop. Clamps or screws + nuts not included.	Recomm	ended use o	5 47W f dedicated a age 23.	ccessories	
		35A - 4 conductors.	•	TR8	3511		
TROLLEY CURRENT		35A - 5 conductors.	•	TR	3512		
COLLECTOR		70A - 4 conductors.		TR8	518		
		70A - 5 conductors.	TR8519				
TROLLEY CURRENT		35A - 4 conductors.		TRE	3516		
COLLECTOR FOR CURVES		70A - 4 conductors.		TRE	3532		

ITEM	PRODUCT	SPECIFICATION	40A 70A 100A 14			140A
TOWING ARM		To use to move the trolley current collector.	•	TR8557		н
TOWING ARM BRACKET		Alternative product of TR8557 (with TR8510).		TR6007		
TOWING ARM		To use with TR6007 or TR8523.		TRE	3510	
DOUBLE TROLLEY SUPPORT		For utilization with two trolleys in order to have ampacity of 140A.	TR8523			
FIXED POINT		To fix the line to control thermal expansion 1 for each line.	TR8527.1			
EXPANSION JOINT	The state of the s	To use to compensate thermal expansion.	TR85H5P07W			
INSPECTION JOINT		To use to exctract the trolley from the line (when there are more than two trolleys).	TDOELLEDOOM			
SECTION JOINT		To use to section the line (double up the number of the trolleys).	TR85H5P45W			
TRANSFER GUIDE				TR85	H5P34	
SPRING LOADED TOWING ARM		For transfer guide.	TR8538			
GASKET IP44			TR8505S			
CONDUCTOR INSERTION TROLLEY		For insertion of copper conductor in the line.	TR8514			
DE-COIL UNIT				TR	3513	



TR85H5P PRE-MOUNTED CONDUCTORS

ITEM	PRODUCT	SPECIFICATION	40A	70A	100A	140A
		Standard lenght: 4 meters *. 4 conductors.	TR85H5P 404CW	TR85H5P 704CW	TR85H5P 1004CW	TR85H5P 1404CW
BUSBAR		Standard lenght: 4 meters *. 5 conductors.	TR85H5P 405CW	TR85H5P 705CW	TR85H5P 1005CW	TR85H5P 1405CW
				Included in B	usbar code	
		Conductor type.	15,5×0,6 9,3mm ²	15,5×1 15,5mm ²	15,5×1,5 23,25mm ²	15,5×2 31mm²
JOINT BOX		Material: plastic. To connect two busbars.		TR85	535W	-
HANGER		Material: plastic. Max support spacing: 1,33 m.		TR8	502W	
CLAMP		Material: steel. Max support spacing: 1,33 m.	TR8525			
END CAP		Material: plastic. Closes and protects the busbar end.		TR8	506W	
FFFD DOV		4 conductors.	TR85H5P03A4W			
FEED BOX		5 conductors.	TR85H5P03A5W			
IN-LINE FEED	FEED To use along the line in order to prevent voltage drop. TR8547W		547W			
		35A 4 conductors.	TR8511			
TROLLEY CURRENT		35A 5 conductors.	TR8512			
COLLECTOR		70A 4 conductors.	TR8518			
		70A 5 conductors.	TR8519			
TROLLEY CURRENT		35A 4 conductors.	TR8516			
COLLECTOR FOR CURVES		70A 4 conductors.	TR8532			

ITEM	PRODUCT	SPECIFICATION	40A 70A 100A 140A		
TOWING ARM		To use to move the trolley current collector.	TR8557		
TOWING ARM BRACKET		Alternative product of TR8557 (with TR8510).	TR6007		
TOWING ARM		To use with TR6007 or TR8523.	TR8510		
DOUBLE TROLLEY SUPPORT		For utilization with two trolleys in order to have ampacity of 140A.	TR8523 TR8527.1 TR85H5P45W		
FIXED POINT		To fix the line to control thermal expansion. 1 for each line.			
SECTION JOINT		To use to section the line (double up the number of the trolleys).			
		LEFT 4 conductors.	TR85H5P34A4W		
TRANSFER		LEFT 5 conductors.	TR85H5P34A5W		
GUIDE		RIGHT 4 conductors.	TR85H5P35A4W		
		RIGHT 5 conductors.	TR85H5P35A5W		
SPRING LOADED TOWING ARM		For transfer guide.	TR8538		
GASKET IP44			TR8505S		



TR85H7P **CONTINUOUS CONDUCTORS**

ITEM	PRODUCT	SPECIFICATION	50A 100/200A* 160/3		160/320A*	
BUSBAR	GIOUENZAN	Standard lenght: 4 meters.	TR85H7PW			
CONDUCTOR SIZE		ETP copper.	12,5×0,8 12,5×1,8 12,5		CSH7160 12,5×2,5 31,25mm ²	
		Material: plastic. To connect two busbars.		TR8501W		
JOINT BOX		Material: steel. To connect two busbars.		TR8524		
HANGER	j	Material: plastic. Max support spacing: 1 m.	TR8502W			
CLAMP Material: steel. Max support spacing: 1 m.		TR8525				
END CAP		Material: plastic. Closes and protects the busbar end.	TR8506W			
FEED BOX		Only for 7 poles till 100A.	TR85H7P005W -		-	
IN-LINE FEED		Clamps or screws + nuts not included.	TR85H7P03W Recommended use of dedicated access to page 23.		ed accessories	
TRANSITION BOX		For parallel connections 200A or 320A.	- TR8564		564	
FIXED POINT		To fix the line to control thermal expansion. 1 for each line.	TR8527.1			
		35A - single.		TR85H7P001		
TROLLEY CURRENT COLLECTOR		70A - double.	TR85H7P002			
		105A - triple.	TR85H7P010			

ITEM	PRODUCT	SPECIFICATION	50A	100/200A*	160/320A*
		Single.		TR8557	
TOWING ARM		Double.		TR8558	
		Triple.		TR8559	
4 POLES		Single (3ph 70A-PE 35A).		TR8561	
TROLLEY CONNECTION		Double (3ph 140A-PE 70A).			
CLAMP		Triple (3ph 210A-PE 105A).		TR8562	
EXPANSION JOINT	The state of the s	To use to compensate thermal expansion.		TR85H7P07W	
INSPECTION JOINT		To use to exctract the trolley from the line (when there are more than two trolleys).		TR85H7P28W	
SECTION JOINT		To use to section the line (double up the number of the trolleys).	TR85H7P45W		
GASKET IP44				TR8505S	
CONDUCTOR INSERTION TROLLEY		For insertion of copper conductor in the line.		TR85H7P14	
DE-COIL UNIT				TR8513	



TR85H7P

PRE-MOUNTED CONDUCTORS

ITEM	PRODUCT	SPECIFICATION	50A	100A	160A	200A*	320A*
		Standard lenght: 4 meters *. 4 conductors.	-	-	-	TR85H7P 1007CW	TR85H7P 1607CW
BUSBAR		Standard lenght: 4 meters. 7 conductors.	TR85H7P 507CW	TR85H7P 1007CW	TR85H7P 1607CW	-	-
		Conductor	*		luded in busba	r code	
		type.	12,5×0,8 10mm ²	12,5×1,8 22,5mm ²	12,5×2,5 31,25mm ²	2X (12,5×1,8) 2×22,5mm ²	2X (12,5×2,5) 2×31,25mm ²
JOINT BOX		Material: plastic. To connect two busbars.			TR85H7P00	7W	
HANGER		Material: plastic. Max support spacing: 1 m.			TR8502W	,	
CLAMP Material: ste		Material: steel. Max support spacing: 1 m.			TR8525		
END CAP	25	Material: plastic. Closes and protects the busbar end.	s TR8506W				
FEED BOX		7 conductors.	TR85H7P005A7W		-	-	
IN-LINE FEED		7 conductors.	TR85H7P03A7W		A7W		
TRANSITION BOX		For parallel connections 200A or 320A.	- TR85		64		
FIXED POINT		To fix the line to control thermal expansion. 1 for each line.	TR8527.1				
		35A - single. TR85H7		TR85H7P0	01		
TROLLEY CURRENT COLLECTOR		70A - double.	TR85H7P002				
		105A - triple.			TR85H7P0	10	

Single. TR8557	ITEM	PRODUCT	SPECIFICATION	50A	100A	160A	200A*	320A*
Triple. TR8559 Single (3ph 70A - PE 35A). TR8561 Double (3ph 140A - PE 70A). Triple (3ph 210A - PE 105A). To use to section the line (double up)			Single.			TR8557		
Triple. TR8559 Single (3ph 70A - PE 35A). TR8561 Double (3ph 140A - PE 70A). Triple (3ph 210A - PE 105A). To use to section the line (double up)	TOWING ARM		Double.			TR8558		
4 POLES TROLLEY CONNECTION CLAMP (3ph 70A - PE 35A). Double (3ph 140A - PE 70A). Triple (3ph 210A - PE 105A). To use to section the line (double up)			Triple.			TR8559		
TROLLEY CONNECTION CLAMP Double (3ph 140A - PE 70A). Triple (3ph 210A - PE 105A). To use to section the line (double up)	4 POLES					TR8561		
Inple (3ph 210A - PE 105A). To use to section the line (double up	TROLLEY CONNECTION	(3pl			TD0F 40			
SECTION the line (double up	CLAMP				1 R8562			
JOINT the nr of the trolleys).			the line (double up the nr of the			w		
GASKET IP44 TR8505S						TR8505S	3	



BUSBAR ACCESSORIES

ITEM	PRODUCT	SPECIFICATION	CODE
	20 ≥ 20 ≥ 20 ≥ 20 ≥ 20 ≥ 20 ≥ 20 ≥ 20 ≥	L=350mm	TR8550
SUPPORT BRACKET	Mounting Example	L=500mm	TR8551
BRACKET (RAIL Fixing)	2 arm clips kit included. THK ≤ 10mm	L=800mm	TR8552
SUPPORT BRACKET	6 20	L=350mm	TR8555
(Wall Fixing)	Wall drilling plan	L=500mm	TR8556
END CAP	25 30 62 52 14 14		30607015

			ACCESSORIES
ITEM	PRODUCT	SPECIFICATION	CODE
TR60 CONDUCTORS CONNECTION CLAMP		Brass material	TR6015
TR85H5P CONDUCTORS CONNECTION CLAMP	20 7 7 7 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9	Brass material	TR8548
TR85H5P CONDUCTORS CONNECTION CLAMP (for IN-LINE FEED)		Brass material	TR8537
TR85H7P CONDUCTORS		Flanged screw M6×12	11606075
CONNECTION KIT		Flanged nut M6	11612013
TR85H5P BRUSH KIT REPLACEMENT	ammin a mining	Only for: TR8518, TR8519, TR8532. One piece for each pole.	TR8520K
TR85H7P BRUSH KIT REPLACEMENT		1x TR85H7P001 2x TR85H7P002 3x TR85H7P010	TR85H7P020K
TR85H7P WHEELS KIT REPLACEMENT		Only for: TR85H7P001 TR85H7P002 TR85H7P010	TR85H7P021K



BUSBAR SYSTEM | CUSTOMIZATION FORM

B	US	B	A	R
		SU	IRV	ΈΥ

COMP	ANY NAME:	CITY:		SURVEY
COUNT		CONTACT:	1.5 LAYOUT DRAWING	
PHONE		MAIL:		
DATE:		REFERENCE:		
1	GENERAL DATA			
1.1	TYPE OF INDUSTRY [] Crane [[] BMU [] Storage [] Other		
1.2	N° MACHINE FOR TRACK			
1.3	N° OF TRACKS			
1.4	TRACK LENGHT	m		
1.5	TRACK LAYOUT	m straight - m curved		
		(please include Layout Drawing on the next page)		
2	ELECTRICAL DATA			
2.1	POWER / CURRENT PER MACHINE	Kw - Inom A - Istart A		
2.2	MAX SIMULTANEOUS CURRENT PER TRACK	A		
2.3	POWER SUPPLY VOLTAGE	V 50/60 Hz - n° phases [] PE [] N		
2.4	CONTROL SIGNALS	Specify number - Voltage		
2.5	SWITCH FREQUENCY AND DUTY CYCLE OF THE MACHINERY	per		
		duty cycle [] 50% [] 60% [] 70% [] 80% [] 90% [] 100%		
3	SYSTEM CONFIGURATION			
3.1	FEED POINT(S) [] At beginning -	[] At m from beginning - [] At m from each end		
3.2	CENTRE DISTANCE HANGERS	m m		
4	MACHINE PARAMETERS			
4.1	TRAVEL SPEED	m/min		
4.2	BUILD DIMENSIONS	Please list if there are any build dimensions to take in consideration		
		(include drawing)		
5	ENVIRONMENTAL DATA			
5.1	INDOOR OR OUTDOOR	[] Indoor [] Outdoor		
5.2	MIN & MAX AMBIENT TEMP.	°C min °C max		
5.3	ENVIRONMENTAL DETAILS	[] Normal [] Dusty [] Humid [] Corrosive [] Other		
6	OPTIONS			
6.1	TRANSFER GUIDES	[] Yes [] No - Quantity		
6.2	SECTION JOINT	[] Yes [] No - Specify the position in the line		
	SECTION JOINT	[] red [] red epoch, the position in the line		
6.3	IP44 RUBBER GASKET	[] Yes [] No		



MULTIPOLE

AVAILABLE VERSION

PRE-MOUNTED CONDUCTORS


The conductors are already inserted in the plastic casing.

MULTIPOLE SYSTEM

The Multipole System is one of the most used insulated system for transmission of power. The main applications of this system are for mobile power consumer: automatic warehouse, light cranes and packaging machinery.

The honeycomb profile guarantees high rigidity and the design of the trolley allow to feed device that have high travel speed (up to 500 m/min).

TYPICAL LAYOUT



1	BUSBAR	PVC Housing
2	TROLLEY CURRENT COLLECTOR	Transmits the energy from the conductor to the machinery
3	HEAD FEED BOX	Connects power supply to the conductors
4	JOINT BOX	Links two busbars
5	END CAP	Closes and protects the busbar end
6	IN-LINE FEED BOX	Connects power supply from centre to the conductors
7	HANGER CLAMP	Connects the busbar to the support (posts, columns)
8	COPPER STRIP	Transmits the energy from the power supply to the current
		collector
9	FIXED POINT	Creates a fixed point to control thermal expansion

TYPICAL APPLICATIONS



CRANE

TECHNOLOGY

Cranes and Hoists

Recycling plans

Galvanized plant



Electric systems

Automated conveyors






PRODUCTION PORT AUTOMATION

TECHNOLOGY RTG cranes

STG cranes

High-bay warehouses Automated storages

STORAGE





MP04P PRE-MOUNTED CONDUCTORS

ITEM	PRODUCT	SPECIFICATION	60A	100A	140A	
BUSBAR		PVC busbar. ETP copper. Lenght of 4 meters. 4 poles.	MP04P060	MP04P100	MP04P140	
JOINT UNIT		Material: nylon and copper. To use to connect two busbar.		MP04P001		
HANGER CLAMP		Material: nylon. 1 or 2 screws to fix. 1 piece each 1 meter.	MP04P002			
FIXED POINT HANGER		Material: nylon. 1 or 2 screws to fix. 1 piece each 1 line.		MP04P014		
END CAP		Material: nylon. To use at the end of the line.		MP04P006		
END FEEDER BOX		Material: nylon and copper. To use to feed the line. Mounted at the extremity of the line.		MP04P003		

ITEM	PRODUCT	SPECIFICATION	60A	100A	140A		
IN-LINE FEED BOX		Material: nylon and copper. To provide intermediate feeding points to reduce voltage drop. Mounted along of the line.	MP04P008				
TROLLEY CURRENT COLLECTOR		50A. Compact. Max deflection: +-15mm.	MP04P011				
		50A. Long. Max deflection: +-30 mm.		MP04P012			



FESTOON SYSTEM

The **festoon system** is the traditional system for energy transmission using a cable. The main applications of this system are mobile power consumers like cranes, monorails, electric hoists, machine tools, car wash systems, plating lines, etc...

This feeding system has several advantages:

- Safety the cables are flame resistant, the conductors are completely protected;
- Versatility it can be used for straight rail as well as for curved rail, for indoor and outdoor applications;
- Easy to install;
- The maintenance of the line is extremely reduced.

AVAILABLE VERSIONS

A. LINE 30

LOAD CAPACITY: 100 kg/m

• **Bar size:** 30 × 32 mm

• Bar lenght: 4 m

B. LINE 41

LOAD CAPACITY: 140 kg/m

• **Bar size:** 39 × 56 mm

• Bar lenght: 4 m

C. LINE 41 STAINLESS STEEL

LOAD CAPACITY: 140 kg/m

• **Bar size:** 39 × 56 mm

• Bar lenght: 3 m

D. LINE WIRE-ROPE

TROLLEY LOAD CAPACITY: 8 kg

• Rope diameter: 8 mm

Travel speed: 40 m/min

E. LINE I-BEAM Light Series

TROLLEY LOAD CAPACITY: 50 kg


• I-beam type: IPE-IPN 80÷100

• Travel speed: 120 m/min

• Max cable capacity: 70 mm










TYPICAL LAYOUT





2 TROLLEY Supports the cable	
TOWING TROLLEY Connects to the mobile device and allows the movem	ent
4 HEAD CLAMP Cable-supporting element without movement	
5 JOINT Connects two C-rail bars	
6 SUPPORT Holds the C-rail bar	
7 END STOP Prevents the exit of the trolley from the C-rail bar	
8 END CAP Closes and protects the C-rail bar	
9 CABLE Transmits the energy	

TYPICAL APPLICATIONS





Cranes and Hoists Recycling plans Galvanized plants



PRODUCTION AUTOMATION

Electric systems Automated conveyors



BMU

Building Maintenance

Units

Airport and terminal stations Skyscrapers Cleanroom technology

PORT

TECHNOLOGY

RTG cranes


STG cranes

NOLOGY STORAGE

High-bay warehouses Automated storage

TECHNICAL DATA


LINE DIAGRAMS




LINE 30 / 41 / 41 Stainless Steel

LINE WIRE-ROPE

LINE I-BEAM





LT = Total lenght H = Height LP = Parking zone lenght LC = Race lenght

BLUE Example

Total line length "LT" = 40 m Height "H" = 2 m Number of trolley/trucks = 12 pcs Parking zone length "LP" = 1,2 m Race length "LC=LT-LP" = 38,8 m

RED Example

Total line length "LT" = 40 m Height "H" = 1 m Number of trolley/trucks = 21 pcs Parking zone length "LP" = 2,2 m Race length "LC=LT-LP" = 37,8 m

33

The diagram is used to determine the number of trolley necessary for the formation of the line, depending on its lenght.

The height of the loop determines how many trolley are needed and thus their parking area. Where the parking area is too long at the expense of running real user, it must increase the height of the loops, thus decreasing the number of trolleys required and therefore the parking area. To determine the cable length of a garland to increase by 10% the total length of the line and add enought to connect the two ends of the fixed and mobile users.



FESTOON LINE 30

7	<u></u>	·	
ITEM	PRODUCT	SPECIFICATION	LINE 30
C-RAIL BAR		Material: steel. Lenght: 4 m. Max load capacity: 100 kg/m.	30607001
JOINT		To connect 2 C-rail bars.	30607002
WALL SUPPORT BRACKET			30607003
CEILING SUPPORT BRACKET		Max support spacing: 1 m.	30607017
SHELF SUPPORT BRACKET	e De la companya della companya della companya de la companya della companya dell		30607004
BRACKET		Lenght: 0,5 m.	30607001/050F
		Lenght: 0,8 m.	30607001/080F
SUPPORT ARM CLIPS		To fix bracket to I-beam. Two pieces each bracket.	30607012
HEAD CLAMP		Saddle: 55 mm. Excursion: 30 mm.	30607020
HEAD CLAWF		Saddle: 76 mm. Excursion: 30 mm.	30607006
TROLLEY		Material: steel. Saddle: 68 mm. Excursion: 35 mm. Max load capacity: 30 kg. Max travel speed: 100 m/min.	30607010
		Material: plastic. Saddle: 55 mm. Excursion: 10 mm. Max load capacity: 15 kg. Max travel speed: 50 m/min.	30607011

			EINE 30
ITEM	PRODUCT	SPECIFICATION	LINE 30
ROUND		For round cable from 10 to 25 mm.	30607021
CABLE TROLLEY		For round cable from 26 to 40 mm.	30607022
EXPANSION FOR ROUND		For round cable from 10 to 25 mm.	30607025
CABLE TROLLEY	I,	For round cable from 26 to 40 mm.	30607026
TOWING TROLLEY		Material: steel. Saddle: 68 mm. Excursion: 30 mm.	30607007
	æ <u>\$</u>	16 poles' socket.	30607027
TROLLEY WITH SOCKET		24 poles' socket.	30607028
	V	Without socket.	30607029
END STOP			30607005
END CAP			30607015
END CAP	N		30607016
CURVED C-RAIL BAR		Curve radius 1200 mm.	30607031
	970	Curve radius 1500 mm.	30607030

	FESTOON	
LINE 41 - 41	STAINLESS STEEL	

ITEM	PRODUCT	SPECIFICATION	LINE 41	LINE 41 STAINLESS STEEL
C-RAIL BAR		41 Steel: 4 m. 41 Stainless steel: 3 m. Max load capacity: 140 kg/m.	30602001/4	30602061
JOINT		Single.	30602002	30602065
		Double. For track > 50 m.	30602034	30602062
WALL SUPPORT BRACKET		Galvanized steel. Max support	30602003	30602063
CEILING SUPPORT BRACKET		spacing: 1 m.	30602004	-
HEAD CLAMP		Saddle: 55 mm. Excursion: 30 mm.	30602071	30602066
		Saddle: 76 mm. Excursion: 30 mm.	30602072	-
TROLLEY		Material: steel. Saddle: 68 mm. Excursion: 30 mm. Max load capacity: 35 kg. Max travel speed: 120 m/min.	30602086	- -
		Material: plastic. Saddle: 55 mm. Excursion: 25 mm. Max load capacity: 20 kg. Max travel speed: 60 m/min.	30602069	30602064
		Material: plastic. Saddle: 76 mm. Excursion: 25 mm. Max load capacity: 20 kg. Max travel speed: 60 m/min.	30602070	-

ITEM	PRODUCT	SPECIFICATION	LINE 41	LINE 41 STAINLESS STEEL
ROUND CABLE		For round cable from 10 to 25 mm.	36602044	-
TROLLEY		For round cable from 26 to 40 mm.	30602045	-
EXPANSION FOR ROUND		For round cable from 10 to 25 mm.	30607025	-
CABLE TROLLEY		For round cable from 26 to 40 mm.	30607026	-
TOWING		Single. Saddle: 68 mm.	30602091	30602067
TROLLEY		Double. Saddle: 68 mm.	30602020	-
		16 poles' socket.	30602041	-
TROLLEY WITH SOCKET		24 poles' socket.	30602042	-
	V	Without socket.	30602043	-
END STOP			30602038	30602068
CURVED C-RAIL BAR	320	Curve radius 1500 mm.	30602054	-







FESTOON LINE WIRE-ROPE AND I-BEAM

ITEM	PRODUCT	SPECIFICATION	MIN. Q.TY	LINE WIRE ROPE
TWIN ROLLER TROLLEY		For flat cable. Saddle: 55 mm. Excursion: 30 mm.	10	30604003
ONE ROLLER TROLLEY		For flat cable. Saddle: 55 mm. Excursion: 30 mm.	10	30604005
ONE ROLLER TROLLEY + METAL CABLE CLIP		For round cable. Max diameter 18 mm.	10	30604007

I-BEAM TYPE	I-BEAM SIZE	SADDLE (mm)	WHEELS	TROLLEY	TOWING TROLLEY	HEAD CLAMP	

	•	EE	PA	30606003	30606033	20606060	
	80	55	steel	30606103	30606133	30606062	
	80	85	PA	30606005	30606035	30606063	
		. 65	steel	30606105	30606135	30000003	
IPE		55	PA	30606011	30606041	30606066	
	100	. 33	steel	30606111	30606141	3000000	
		85	PA	30606013	30606043	30606067	
			steel	30606113	30606143		
	80 –	55	PA	30606004	30606034	30606062	
			steel	30606104	30606134	30000002	
		00	85	PA	30606006	30606036	30606063
IPN		. 65	steel	30606106	30606136	30000003	
		55	PA	30606012	30606042	30606066	
	100		steel	30606112	30606142	3000000	
	100	85	PA	30606014	30606044	30606067	
		. 55	steel	30606114	30606144	0000007	

FESTOON SYSTEM



PVC FLAT CABLE ANTI-AGING H07VVH6-F

- Particularly suitable for supply and control circuits, lifting and handling equipment. Comply with: CEI 20-22 II (flame resistant). Rated operating voltage: 400V. Max short circuit temparature: 160°C.

- Insulation class: 2/3.
- Rated insulation voltage: Uo/U 450/750V.
- Operating temperature: -5°C ... +70°C.
 Internal conductors with flexible PVC sheath progressively numbered, plus earth conductor (yellow/green).
- On request the cables can be supplied with a tinned red copper shield heat resistant up to 105° C (minimum requirement is 2000 m). Blue colour sheath. Finish the order code with "N" for the black sheat.

CODE	N° COND. X CROSS SECTION	OUTER SIZES (mm)	STRAND (N°/mm)	WEIGHT (gr/m)	TOTAL CROSS SECTION (mm²)	ELECTRICAL RESISTANCE 20°C (ohm/km)	MAX CURRE TEMPERATO FIXED	NT AMBIENT URE 30°C (A) MOVED
CP0415AF	4 × 1,5	15 × 5,2		150	6	•	19,5	17
CP0815AF	8 × 1,5	29 × 5,5		300	12	•	12	10
CP1215AF	12 × 1,5	41 × 5	30 × 0.25	420	18	13,30	11	9,5
CP1615AF	16 × 1,5	54 × 8	30 × 0,23	510	24	13,30	10	8,5
CP1815AF	18 × 1,5	43 × 11	·	700	27		9,5	8
CP2415AF	24 × 1,5	51 × 13		1000	36	•	9	7,5
CP0425AF	4 × 2,5	21 × 5,7		240	10		26	22,5
CP0825AF	8 × 2,5	33 × 6		420	20	•	18	13
CP1225AF	12 × 2,5	50 × 7	- 50 005	640	30	7,98	17	12
CP1625AF	16 × 2,5	41 × 13	50 × 0,25	1000	40	7,90	16	11
CP1825AF	18 × 2,5	50 × 13		1050	45		15	10
CP2425AF	24 × 2,5	54 × 13		1100	60		14	9
CP0404AF	4 × 4	21 × 7,5	F6 0.20	330	16		35	30
CP0804AF	8 × 4	38 × 5	56 × 0,30	550	32	4,95	24	19
CP0406AF	4×6	24 × 8	04 000	440	24	2.20	46	40
CP0806AF	8×6	38,5 × 8	84 × 0,30	742	48	3,30	32	25
CP0410AF	4 × 10	35 × 11	7 × 12 × 0,40	800	40	1,91	57	46
CP0416AF	4 × 16	36,5 × 12	7 × 18 × 0,40	1200	64	1,21	76	62
CP04250AF	4 × 25	43 × 13	7 × 28 × 0,40	1700	100	0,78	96	80
CP0435AF	4 × 35	50 × 14	7 × 39 × 0,40	2050	140	0,55	119	99

12903010	Standard	FLAT CABLE	37	96 GIOVENZANA
12903011	ø28.5 out	GLAND	9	INTERNATIONAL 56

FESTOON SYSTEM

FESTOON CABLES

ROUND CABLE WITH DUAL STRAIN RELIEF STEEL ROPES S05VVD7-F

- Made for heavy duty applications, in particular for pendant push button stations and moving electromechanical components.
- The two strain relief ropes avoid any stress on the cable; they are embedded, diametrically opposed to PVC sheath.
- Comply with: CEI 20-22 II (flame resistant). Rated operating voltage: 230V.
- Max short circuit temparature: 160°C.
- Ø2mm steel strain relief ropes.
- Insulation class: 2/3.
- Rated insulation voltage: Uo/U 300/500V.
 Operating temperature: -5°C +70°C.
 Breaking point: 60kg/mm².

- Internal conductors with flexible PVC scheath progressively numbered, plus earth conductor (yellow/green).
- Blue colour sheath. Finish the order code with "N" for the black sheat.

CODE	N° COND. X CROSS SECTION	OUTER CABLE Ø (mm) approx	STRAIN RELIEF ROPE	STRAND (N°/mm)	WEIGHT (gr/m)	TOTAL CROSS SECTION (mm ²)	ELECTRICAL RESISTANCE 20°C (ohm/km)	MAX CURRENT AMBIENT TEMPERATURE 30°C (A) FIXED MOVED	
CT0815AUAF	8 × 1,5	11,6	23,6	30 × 0,25	225	12	13,30	12	10
CT1215AUAF	12 × 1,5	14,4	26,4		315	18		11	9,5
CT1615AUAF	16 × 1,5	16	28		415	24		10	8,5
CT1815AUAF	18 × 1,5	17	29		470	27		9,5	8
CT2015AUAF	20 × 1,5	18	30		525	30		9	7,5
CT2415AUAF	24 × 1,5	21	33		620	36		8,5	7

BREAKING NEWS





TRV VERTICAL BUSBAR

Designed for lifting tasks in Material Handling Systems and Outdoor and Construction Site Lift Technology

Ask more to giovenzana@giovenzana.com

VERTICAL BUSBAR SYSTEM WITH 6 PRE-MOUNTED CONDUCTORS

Energy transmission system fitted with 6 conductors with joints. Operating current: 50, 100 or 160 A, depending on the busbar.

Vertical layout suitable for construction site lifts.

TRV06P006

End cap: Close and protect the end of the busbar.

TR6012

Gasket: In high-performance elastic PVC.

TRVS06P160

Switch disconnector: The switch allows to interrupt current within a TRV line to allow the line to be extended in length without having to intervene on the main switch.

On request.

TRV06P...

Insulated bar 50A / 100A / 150A: Rigid PVC housing with 6 enclosed copper conductors.

At each extremities, the copper strip has connector for electrical and mechanical connection with next bar.

TRV06P011

Trolley current collector: To provide power to construction hoist. Carbon brushes with springs guarantee uniform electrical contact.

TRV06P001

Connection box: Composed by a joint box, baseplate with connectors and two joint covers. Connectors are mounted on a baseplate. The phases on busbar are engaged to it guarantee both mechanical and electrical continuity.

TRV06P003

Feeding box: Composed by insulated bar, it provides connection between system and cable inside the relevant box.

SMART SOLUTION AVOID THE CONVENTIONAL CABLE DISTRIBUTION SYSTEM!

ENERGY TRANSMISSION LINES www.giovenzana.com

Optimization of space.

The compact design of the cable-free bar allows optimization of installation and use space.

It is the safety response to a problem that has never been solved.

It can solve the problem of conductor interruption in the power cable currently used to power construction site elevators. There is no problem of damage or wear on the cable.

Provides easier and faster installation.

The interlocking modularity of the individual components means that no tools are needed for installation and less construction work means less expensive installation.

Flexibility of use.

Compatible with any type of structure and any configuration.

It is a unique solution, an excellent alternative to cable replacement.









